

Linux driver

The Linux public driver supports most of the Linux distribution, including Ubuntu, Debian, SuSE(openSuSE), Fedora Core, Mandriva, Slackware and so on. Please according to your kernel version, download corresponding driver.

kernel	X86/x-windows		Arm/mips	Multi-touch
	32 bits	64 bits		
3.x.x/4.x.x	✓	✓	✓	✓
2.6.36 upward	✓	✓	✓	✓
2.6.24~35	✓	✓	✓	×
2.6.23 downward	✓	✓	×	×
2.4.x	✓	×	×	×

Kernel 2.6.24 Upward and 3.x.x / 4.x.x	USB / UART
X86 (32/64bits)	eGTouch v2.5.5814.L-x
ARM / MIPS	eGTouch v2.5.5814.L-ma
1. Available for multi-touch as kernel version is 2.6.36 above. If kernel version below 2.6.35, it could only support single point. 2. Available for non-Xwindow system. 3. Support Multi-controller & Multi- monitor. 4. Support Right-Click	

Kernel 2.6.23 Downward	USB / UART
X86 32bits (Need X-window)	eGalaxTouch 3.07.6014-32b
X86 64bits (Need X-window)	eGalaxTouch 3.07.6014-64b
1. X-window is needed. 2. Only support single mouse point. 3. Support Multi-controller & Multi-monitor. 4. Support Right-Click	

Kernel 2.4.X	USB / UART
X86 32bits (Need X-window)	eGalaxTouch 3.06.5605-32b
1. X-window is needed. 2. Only support single mouse point. 3. Support Multi-controller & Multi-monitor. 4. Support Right-Click	

Customization Touch Driver for SUSE Linux Enterprise Desktop 11 SP3

X86 32bits	eGalaxTouch-3.13.10330-32b
X86 64bits	eGalaxTouch-3.13.10330-64b
*Important: This customized touch driver is for specific All-in-One POS systems only. Only support single mouse point.	

